

Craftstone Take Off Guide

Understanding M2 & LM

M2 (Square Metres)

Applies to Flat Area
Calculate Width x Height

LM (Lineal Metres)

Applies to Corner Area
Calculate Length of each corner that requires corner pieces


DEDUCTIONS

Remove M2 or LM that do not require stone




Formula: Total Stone Required

= (wall area) - (window + door area) - (wall area covered by corners)



Formula: Total Stone Required

= (wall area) – (window + door area) – (wall area covered by corners)




Formula: Total Stone Required

= (wall area) – (window + door area) – (wall area covered by corners)

Formula: Wall Area Covered by Corners:

Lineal Metres of Corners x 0.2




Why Allow 5% for Waste?

- Allows for Good Selection of Stone Sizes & Shapes for a Professional Finish
- Eliminates the Risk of finishing the job with similar colour or sized pieces


Why Allow 10-25% for Tight Fitting?

- Cultured Stone is Sold based on using a 12mm Mortar Joint
- When stone is fitted with no mortar joint, it requires more stone to fill up a square metre
- Always ask customers what type of Mortar Joint they require
 - Standard 12mm
 - Tight Fitted

Why Allow 10-25% Extra for Tight Fitting?



Standard 12mm



Tight Fitted

Profile	Standard Joint	Tight Fitted Joint
Craftbricks Cottage	5%	N/A
Vintage Ledgestone	5%	N/A
Classic Ledgestone	5%	N/A
Country Ledgestone	5%	N/A
Mountain Ledgestone	5%	20%
Stacked Ledgestone	5%	20%
Weathered Ledgestone	5%	20%
Medieval Castle Stone	5%	N/A
Sand Stone	5%	N/A
River Rock	5%	N/A
Quarry Stone	5%	25%

- Allow 5% for Wastage across all Profiles
- Allow 10-25% for Tight Fitted
 Joints Refer to Table
- Always ask customers what type of Mortar Joint they require?